

## A. DRIVER FLOORBOARD MOUNTING BRACKET

Chrome driver floorboard mounting bracket. Fits 83'-06' FLT, FLHT (4 pieces). **SOLD AS KIT**

**123-30** Chrome floorboard mounting bracket. OEM 47398-04.



## B. FRAME MOUNT RIDER PEG BRACKET FOR SPORTSTER®

**23-108** Fits Sportster® 1954 thru 1978 stock swing arm only. **SOLD EACH**

## C. FRAME MOUNT RIDER PEG BRACKET FOR BIG TWIN

Mounts to transmission plate on H-D® kickstart. May be modified to fit electric start. Gives lower peg location for passenger comfort. Bolt holes for peg mounting are 1/2" diameter.

**23-52** For Big Twin rigid frame. **SOLD EACH**



## D. H-D® STYLE FLOORBOARDS THREE STYLES TO CHOOSE FROM

### EARLY STYLE MOUNTS

Fits 1940 thru 1984 4 speed models.

**123-5** Solid oval floorboards. Replaces OEM 50603-40. **SOLD AS PAIR**

**123-4** Anti-vibe oval floorboards.

**123-10** Anti-vibe rectangular floorboards. Replaces OEM 50603-74TA.

### LATE STYLE MOUNTS

Fits 1980 & later 5 speed FL, Softail®, Road King® & FLT.

**123-20** Solid oval floorboards. **SOLD AS PAIR**

**123-21** Anti-vibe oval floorboards. Replaces OEM 50599-89T.

**123-29** Anti-vibe rectangular floorboards. Replaces OEM 50621-79A.

### REPLACEMENT PARTS

**123-6** Oval replacement rubber pads. **SOLD AS PAIR**

**123-11** Rectangular replacement rubber pads. OEM 50614-66T.

**123-12** Anti-vibe bumpers. OEM 50620-74. **SOLD AS SET OF EIGHT**



## E. ADJUSTABLE FLOORBOARDS

Oval style floorboards are adjustable front to back as well as height and angle. They will fit Softail® 1984 & later except Fat Boy®, Heritage Softail® and FXWG 1980 thru 1986.

**123-18** Anti-vibration adjustable floorboards. **SOLD AS KIT**

**123-19** Standard adjustable floorboards.

**E**

